


Quick Menu: Quick And Easy.
The Quick Menu¹ offers shortcuts to key i-Guide features. Just press MENU on your remote anytime while using the guide or watching TV, and you'll have easy access to programming like HD, On Demand and Kids, plus key features like Search, Parental Controls and more.



Press the ◀ ▶ on your remote to highlight an option, press OK and you're on your way.



Press MENU button twice for the Main Menu.




Enhanced Searching.

With i-Guide find what you want easily by searching Listings By Time, Listings By Channel or by program category. You can also search by category or program title. The Search Menu is easily accessed from the 🔍 on the Quick Menu or from the Main Menu.



When searching by category such as Movies, Sports or Kids, you can focus your search further by subcategories. For example, search for movies that fit your mood by Comedy, Drama, Musicals and more.



When you find a program you like, press OK to make the Flip Bar disappear or press INFO for more program details.

Smart Channel Surfing.

The Flip Bar lets you see program information as you change channels.




The Mini Guide lets you watch television and view listings without having to leave your program. To access, press OK or INFO then use the ◀ ▶ buttons to browse time and use the ▲ ▼ buttons to browse channels.

Program Information At Your Fingertips.

i-Guide provides Instant Information while you view program listings, including program title, start/end time, program rating and a brief description including TV content ratings. You'll also see helpful indicators that identify settings, such as Reminders, Recordings and Favorites.



For more detailed information, press the INFO button on your remote.



Blue – Regular programs
Purple – Movies
Green – Sports
Light Blue – Children's programs

Action Icon Shortcuts.

Press INFO to learn more about a program. From this Program Information screen, you can use the Action Icons at the bottom to set a Recording or Reminder, set up Parental Controls and more.




Use the arrow ◀ ▶ buttons to highlight an icon, a description will appear just below the icons.

Parental Controls To Protect Your Family.

Parental Controls allow you to restrict viewing and purchases of TV programs based on your preferences. Set a personalized 4-digit PIN to place locks on selected movie and TV ratings, TV content ratings, channels and titles. You can also hide adult titles from being displayed on screen.



Select 🔒 from the Quick Menu to set up Parental Controls and PINs.




Go Ahead, Play Favorites.

i-Guide's Favorites feature lets you you design up to five Favorites lists – one for everyone in the family. Just select My Favorite Channels from the Main Menu or ❤️ from the Quick Menu.

Pay-Per-View,² Made Easy.

Ordering PPV movies and events is easy with i-Guide. From the Main Menu or Quick Menu, select any of the PPV options to see a list of available programs. Use your remote to get detailed information, watch a preview and place an order.

If your PPV program is scheduled to air at a future time, a Reminder is automatically set to appear before your program begins.



On Demand²

With On Demand you can rent movies or programs from the On Demand library and watch shows at your convenience, as many times as you want within the rental period. You can even pause, fast-forward and rewind.



Access On Demand programming from Main Menu, Quick Menu or a channel in the TV Listings.

introducing i-Guide.™

The interactive programming guide from TV Guide. It’s intuitive, intelligent and inspiring. i-Guide unlocks a world of greater choice, convenience and control as you watch television.

With i-Guide you’ll enjoy:

- A sleek design
- A convenient, time-saving Quick Menu
- A friendly display with a full 90 minutes of programming listings
- Enhanced search and parental controls
- Increased speed
- And Mini Guide, a whole new way to watch TV and surf at the same time

Try i-Guide. In no time, you’ll be able to set Reminders, Favorites, Parental Controls, and use our Mini-Guide to find out what’s next, while you continue to watch your favorite shows. Plus, you’ll have access to great features like On Demand, HD and DVR.¹

With i-Guide, the world is at your fingertips.

RemoteControlFeatures

Basic Navigation

- **Yellow** is always the highlight color. As you navigate listings using the remote, the highlight appears on screen to indicate the current selection.
- Press the **Left/Right** or **Up/Down** buttons to move the highlight.
- Press **OK** to make a selection.
- Press the **EXIT** button to return to watching TV.



Digital Video Recording (DVR)² Puts You In Control.

Pause live television. Rewind and replay programs. Record your favorites – even HD programming – all season long. With DVR, you’re in control from the comfort of your own home. And with Dual-Tuner DVR, you can watch one program, while recording another.²



Control Live TV.

Any time you tune to a channel, the DVR starts a temporary recording. So you can **PAUSE** if the phone rings, **REWIND** the scene you missed and **FAST-FORWARD** to skip what you don’t want to watch.

Three Ways To Record.

Press **RECORD** on your remote any time while watching TV or navigating through the guide for easy, one-touch recording. You can also record by program or manually schedule a recording.

Many Ways To Play.

Your DVR offers many playback controls right from your remote control. **PAUSE** to freeze, press **PLAY** to resume. **REWIND** up to 4 times to increase the rewind speed. **FAST FORWARD** up to 4 times to increase FF speed. **PAUSE** and then **FAST FORWARD** or **REWIND** for slow motion. To return to regular speed, press **PLAY**. **PAGE** **Down Arrow** or **REPLAY** button¹ to replay the last 15 seconds. Press the **Up Arrow** button or **LIVE** button³ on your remote button.

¹ Menu selections vary depending on the services your cable provider offers.
² PPV, On Demand and DVR not available in all areas. On Demand programs may not be recorded with DVR. DVR recording capacities vary. Dual-Tuner DVR optional feature, where available.
³ May not be supported on all remotes.



inside i-Guide™
Quick Reference Guide

